













Process Name/Title: <b>Proper Wire insertion to Connector</b>		Document No:		<b>WI-PRO-ASY-161</b>	
		WORK INSTRUCTION		Effective Date:	
Product Code/Name: <b>All</b>		Customer Code: <b>All</b>		Rev.No.: 4	Page No.: 1 of 4

No.	Work Procedure / Illustration						Records/Remarks/ Quality Pointers			
1	Wire Insertion to Connector		<div><div><p>wire without waterproof seal</p><p>wire with waterproof seal</p><ul style="list-style-type: none"><li>Hold the wire at least 10mm away from the terminal</li></ul></div><div><p>Insert the terminal into the connector</p><ul style="list-style-type: none"><li>Fully insert the wire terminal into the connector</li></ul></div><div><p>Conduct checking of insertion condition</p></div></div>			<ul style="list-style-type: none"><li>Make sure wires are properly inserted. Confirm insertion by <b>2x PULL-PUSH</b>.</li></ul> <p><b>NOTE:</b>Refer to GL-PRO-ASY-029 for Pull-push procedure.</p>				
			<div><div><p><b>NG CONDITION OF WIRE INSERTION</b></p><p><b>IMPROPER HANDLING OF WIRE</b></p><p>Holding the wire close to terminal</p></div><div><p><b>NOT FULLY INSERTED WIRES/ TERMINAL BACKING OUT</b></p><p>Cannot fully insert terminal on connector due to finger hits connector</p></div><div><p><b>NOTE:</b> Terminal backing out may occur if wires are not fully inserted which can cause malfunction.</p><p>Sample photo of Terminal Backing Out (from Customer Claim)</p></div></div> <div>Be sure to follow the instructions when an abnormality occurs during work</div>							
10/18/2024	4	Additional work procedure for Hazard models (page 4)			K.Hernandez	K.Aquino	W. Carbillon	Prepare	Check	Approve
11/3/2023	3	Additional work procedure for steering models for wire insertion with pre-asy tube (page 3)			A. Morcozo	C. Calayan	W. Carbillon			
6/21/2023	2	Additional work procedure for steering models (page 2)			A. Morcozo	C. Calayan	O.Merin			
9/13/2022	1	Improve work procedure and illustration for proper holding of wire during insertion. Include sample photo of terminal backing out from customer claim			C. Recto	W.Carbillon	O.Merin			
Eff./Rev. Date	Rev. No	Details of change			Revise	Check	Approve	Est. date: 09/07/2019		








**CONFIDENTIAL:** Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

**NBC (Philippines)**  
**MASTER COPY**

DCC Stamp


	Process Name/ Title:		Document No:		WI-PRO-ASY-161	
	Proper Wire insertion to Connector		Effective Date:		October 18, 2024	
	WORK INSTRUCTION		Rev. No.:		4	
	Product Code/Name:	Customer Code:	Page No.:		2 of 4	
	Steering	ALL				








  

No.	Work Procedure/ Illustration	Records/Remarks/ Quality Pointers
1	<div>Get one wire from the tube using right hand</div>  <div>Check terminal appearance NOTE: Should have <b>no visible deformation</b> on terminal</div>  <div>Hold the wire <b>10 mm</b> away from terminal</div>  <div>Align the facing of terminal then insert it to proper terminal slot</div>  <div>NOTE: BACK VIEW OF TERMINAL SHOULD BE FACING UPWARD DURING WIRE INSERTION</div> <div> <div>Proper alignment of terminal to connector</div>  <div>Improper alignment of terminal to connector</div>    <div> <div>BACK VIEW OF TERMINAL</div> <div>FRONT VIEW OF TERMINAL</div> <div>GOOD Terminal condition</div> <div>GOOD Terminal condition</div> </div> <div> <div>BACK VIEW OF TERMINAL</div> <div>FRONT VIEW OF TERMINAL</div> <div>NO GOOD Terminal condition</div> <div>NO GOOD Terminal condition</div> </div> </div> <div>Conduct <b>2x pull-push</b> checking</div>  <div>2x pull-push</div>	<p><b>NOTE:</b> Refer to specific work instructions per model</p> <p><b>NOTE:</b> No deformed terminal</p> <p><b>NOTE:</b> Conduct <b>STOP-CALL-WAIT</b> when encountered any abnormality</p> <p><b>NOTE:</b></p> <ul style="list-style-type: none"> <li>&gt; No bend wire</li> <li>&gt; Make sure the terminal is in proper alignment before insertion</li> <li>&gt; Avoid hitting the terminal into connector during wire insertion. If encountered abnormality, conduct STOP-CALL-WAIT</li> </ul> <p><b>Remiders / Note :</b></p> <ul style="list-style-type: none"> <li>&gt; Do not attempt to repair</li> <li>&gt; Automatically disposed and replace the wire once encountered bumped terminal during insertion, difficulty of insertion and bend terminal .</li> </ul> <p>If encountered abnormality (ex. wrong insert) conduct <b>STOP-CALL-WAIT</b></p> <p>&gt; Refer to GL-PRO-ASY-029 for Pull-push procedure</p>


  

<b>CONFIDENTIAL:</b> Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.	<b>NBC (Philippines)</b> <b>MASTER COPY</b>	DCC Stamp
--	--	-----------

	Process Name/ Title:		Document No:		WI-PRO-ASY-161	
	Proper Wire insertion to Connector					
	WORK INSTRUCTION		Effective Date:		October 18, 2024	
	Product Code/Name:		Customer Code:		Rev. No.: 4 Page No.: 3 of 4	
Steering		ALL				

No.	Work Procedure/ Illustration	Records/Remarks/ Quality Pointers																													
1	<div><div>Wire Insertion (Pre-assy- with tube)</div><div>Hold the tube (near wire terminal to be inserted)</div><div>Pull down the tube prior wire insertion</div><div>Check the Wire Color BEFORE and AFTER insertion</div><div>SAMPLE MODEL: 75N860-0021</div><div><div><div>GOOD PRODUCT</div><div>(CORRECT INSERTED WIRE COLOR)</div><div></div><div>RL-R-OR</div></div><div><div>NG PRODUCT</div><div>(WRONG INSERTED WIRE COLOR)</div><div></div><div>OR-R-RL</div></div></div><div><div>WIRE INSERTION SEQUENCE</div><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr><tr><td>B/W</td><td>B</td><td>V</td><td>LG</td><td>GR/B</td><td>Y</td><td>R/L</td><td>R</td><td>OR</td><td>R/W</td></tr><tr><td>288</td><td>152</td><td>157</td><td>288</td><td>152</td><td>157</td><td>288</td><td>151</td><td>288</td><td>288</td></tr></table></div></div> <div><div></div><div><div></div><div></div></div><div><div></div><div>Exposed length to see the wire color</div><div>Enough space between tubes</div></div><div></div></div> <div><div>NOTE: Refer to specific work instructions per model</div><div>NOTE: &gt; Make sure the wire have enough exposed length to see the wire color &gt; No wrong insert &gt; No bend wire &gt; Make sure the terminal is in proper alignment before insertion &gt; Avoid hitting the terminal into connector during wire insertion. If encountered abnormality, conduct STOP-CALL-WAIT</div><div>NOTE: &gt; Make sure the wire have enough exposed length to see the wire color &gt; Make sure there is enough space between tubes</div><div>NOTE: Refer to page 2 for proper wire insertion</div><div>NOTE: &gt; No wrong insert &gt; If encountered abnormality (ex. wrong insert) conduct STOP-CALL-WAIT</div></div>	1	2	3	4	5	6	7	8	9	10	B/W	B	V	LG	GR/B	Y	R/L	R	OR	R/W	288	152	157	288	152	157	288	151	288	288
1	2	3	4	5	6	7	8	9	10																						
B/W	B	V	LG	GR/B	Y	R/L	R	OR	R/W																						
288	152	157	288	152	157	288	151	288	288																						



		Process Name/ Title:		Document No:		WI-PRO-ASY-161	
		Proper Wire insertion to Connector					
		WORK INSTRUCTION		Effective Date:		October 18, 2024	
		Product Code/Name:		Customer Code:		Rev. No.: 4 Page No.: 4 of 4	
		HAZARD		ALL			

No.	Work Procedure/ Illustration	Records/Remarks/ Quality Pointers
4	<div>Get one wire from the tube using right hand</div> <div>Check terminal appearance NOTE: Should have <b>no visible deformation</b> on terminal</div> <div>Hold the wire <b>10 mm</b> away from terminal</div> <div>Align the facing of terminal then insert it to proper terminal slot</div> <div>Conduct <b>2x pull-push</b> checking</div>	<div>4</div> <div><b>NOTE:</b> Refer to specific work instructions per model</div> <div><b>Quality pointers :</b> No deformed terminal</div> <div>Conduct <b>STOP-CALL-WAIT</b> when encountered any abnormality</div> <div><b>Quality pointers :</b> <div>1. No wrong insert</div><div>2. No bend terminal</div><div>3. Make sure the terminal is in proper alignment before insertion</div><div>4. Avoid hitting the terminal into connector during wire insertion.</div></div> <div><b>Remiders / Note :</b> <div>&gt; Do not attempt to repair</div><div>&gt; Automatically disposed and replace the wire once encountered bumped terminal during insertion, difficulty of insertion and bend terminal .</div></div> <div>If encountered abnormality (ex. wrong insert) conduct <b>STOP-CALL-WAIT</b></div> <div>&gt; Refer to GL-PRO-ASY-029 for Pull-push procedure</div>